



## SP2W Solar Charger Installation Instructions

*For Texas Hunter Directional Feeders*

Thank you for your purchase of the SP2W Solar Charger.

**Maximize the Sun's Energy.** Your New Texas Hunter Feeder is pre-wired for the SP2W Solar Charger. The solar charger can be mounted on any side of the unit to maximize the sun's energy. After determining the location for your feeder, select the side of the unit that faces the south to ensure the most sunlight exposure per day.

**Tools Needed:** (✕) Phillips head screw driver.

### Installation:

- 1) Remove the two screws to the left and right of the black plastic grommet on the feeder's side facing the south. Keep these screws for re-installation (Step 3). Note: If you mount the solar charger on the same side of the feeder where the feed is dispensed (above the blower unit), be sure to clean it regularly as dust from the feed may settle on the panel and reduce it's effectiveness over time.
- 2) Insert the solar cable through the grommet by pushing from the outside through the grommet into the feeder.
- 3) Hold solar charger against side of unit and re-install the two sheet metal screws.
- 4) Plug the solar charger's white plug into the matching plug on the timer. The solar charger will charge the battery through the timer.

### Operation / Maintenance:

- 1) The rechargeable battery should be fully charged before solar charger installation. (note: Batteries sold with Texas Hunter Feeders are already charged).
- 2) Charger should be in the open, not under trees, shrubs or other obstructions.
- 3) Keep face of panel clean to ensure that it captures the most sunlight each day.

Thank you for your purchase. Please call (800) 969-3337 if we can be of assistance.